

Magnetic Charging Accessories

Easily charge your Automate shades with the Magnetic Charging Accessories. Simply snap the magnetic charging cable in place and pull off when fully charged.



MT03-0304-036022 AUTOMATE | Magnetic Connector USB C



MT03-0304-036014 AUTOMATE | Magnetic Connector Micro B





ARC[™] (Automate Radio Communication) is Rollease Acmeda's proprietary technology utilizing 433MHz radio communication with bi-directional feedback that brings Automate motorized shading systems together.

Product Specifications

Part #: MT03-0304-069015AUTOMATE | Magnetic Extension Cable 3MPart #: MT03-0304-036014AUTOMATE | Magnetic Connector Micro BPart #: MT03-0304-036022AUTOMATE | Magnetic Connector USB C

	Magnetic Cable	Magnetic Connector (USB C & Micro B)
Vmax	5V	
Imax	2А	
Charging Indicator	Blue LED	
Weight	0.5 oz	0.30 oz

Charging Process

Dimensions




1. Connect the Magnetic Tip the motor head



2. Check if the Green LED on the Magnetic Cable is blinking (blinking equals charging)

NOTE: For best experience, ensure that the motor is installed with the charging port facing downwards.



MT03-0304-xxxxxx_ Magnetic Charging Accessories_v1.0_November 2024